



Office: 816-779-5947 - Cell: 913-208-2183 - austin@kansascityatticfans.com
26305 Owens Lane, Freeman, MO 64746

Attic Fan Pre-Wiring Instructions

Fan should be on its own 15amp breaker

Install two single gang boxes in the wall. Typically these are installed one on top of the other at about an inch or less apart. One for the high low speed setting and one for the timer.

Bottom box is the timer and has a 14-2 wire from the box to the electric panel

From the bottom box to the top box is a 14-2 wire

From the top box to the fan is a 14-3 wire

KC Attic Fans will be responsible for connecting these existing wires to the fan, timer and 2 speed switch. KC Attic Fans provides the timer and 2 speed switch.

